


Do not scale from this drawing except for planning purposes. All dimensions must be checked on site before any work begins.

© Ecotecture Ecological Design Limited.

Drawing to be printed A3




ecotecture
ECOLOGICAL ARCHITECTURE

www.ecotecture.co.uk

Client: David Thackeray

Description: New Dwelling Eaves Detail

Drawing No: 805/353



Good Practice Guide:

1. Insulation to entirely fill eaves gap between wall insulation and floor insulation
2. Install insulation before eaves are inaccessible
3. Install insulation tightly butted with no gaps
4. Cut insulation tight to cavity closers, lintels and cavity trays
5. Install insulation before floor and wall junction is inaccessible