



Boundary Box	Break Pressure Tank	Capped End	Hydrant
□ Boundary Box	BPT Break Pressure Tank	□ Capped End	▲ Emptying Plug ○ Fire Hydrant ○ WOH Washout Hydrant
Pressure Monitoring	Service Reservoir	Meter	Valve - Controllable
● Logger	● Covered	● Tower	● Meter Open Valve + Closed Valve X Stop Tap
Site	Valve - Flow		
◊ Abstraction Point ● Booster Station ● Surface Reservoir	● Supply Works ● Transfer Station ● Underground Source	AV Air Valve PRV Pressure Reducing Valve	NRV Non-Return Valve PSV Pressure Sustaining Valve
		WO Washout Empty Valve	— Pipe Bridge
Valve - Pressure		Pipe Bridge	
	●	●	— = Pipe Bridge
Water Pipe	Water Area		
— Communication — Distribution — Non-Potable	— Trunk — Raw — Private	— Decommissioned	■ Water Supply Zone □ District Meter Area

Map Title: SW Print

Printed By: Kelly.Donaldson

Date Printed: 12/05/2025

Map Scale: 750

The information provided is believed to be correct but is provided on an 'as is' basis and without any warranty or condition express or implied, statutory or otherwise as to its quality or fitness for purpose. Actual positions of assets should always be determined on site.



from
Southern Water.