

Porsche Mid Sussex – SuDS Maintenance statement

Table 1 Typical inspection and maintenance requirements

Activity	Indicative frequency	Typical tasks
Routine/regular maintenance	Monthly (for normal care of SuDS)	• litter picking • grass cutting • inspection of inlets, outlets and control structures.
Occasional maintenance	Annually (dependent on the design)	• silt control around components • vegetation management around components • suction sweeping of permeable paving • silt removal from catchpits, soakways and cellular storage. • Clearance of open drainage ditch and headwalls.
Remedial maintenance	As required (tasks to repair problems due to damage or vandalism)	• inlet/outlet repair • erosion repairs • reinstatement of edgings • reinstatement following pollution • removal of silt build up.

Access Consideration for maintenance Works

All maintenance works can be carried out from within the site. There is sufficient space for parking vehicles. Access to drainage ditch and pond is readily available. Obstruction of highways will be prohibited.