



Boundary Box	Break Pressure Tank	Capped End	Hydrant
<input type="checkbox"/> Boundary Box	<input type="checkbox"/> BPT	<input type="checkbox"/> Capped End	<input type="checkbox"/> Emptying Plug
			<input type="checkbox"/> Fire Hydrant
			<input type="checkbox"/> WOH Washout
			<input type="checkbox"/> OH Hydrant

Pressure Monitoring	Service Reservoir	Meter	Valve - Controllable
<input type="checkbox"/> Logger	<input type="checkbox"/> Covered	<input type="checkbox"/> Tower	<input type="checkbox"/> Meter
			<input type="checkbox"/> Open Valve
			<input type="checkbox"/> Closed Valve
			<input type="checkbox"/> Stop Tap

Site		Valve - Flow		
<input type="checkbox"/> Abstraction Point	<input type="checkbox"/> Supply Works	AV	Air Valve	NRV
<input type="checkbox"/> Booster Station	<input type="checkbox"/> Transfer Station		Non-Return Valve	WO
<input type="checkbox"/> Surface Reservoir	<input type="checkbox"/> Underground Source	PRV	Pressure Reducing Valve	PSV
			Pressure Sustaining Valve	Pipe Bridge
				<input type="checkbox"/> Pipe Bridge

Water Pipe		Water Area	
Communication	Trunk	Decommissioned	<input type="checkbox"/> Water Supply Zone
Distribution	Raw	<input type="checkbox"/> Discolouration	<input type="checkbox"/> District Meter Area
Non-Potable	Private		

Map Title: SW Print

Printed By: Kelly.Donaldson

Date Printed: 04/03/2025

Map Scale: 500

The information provided is believed to be correct but is provided on an 'as is' basis and without any warranty or condition express or implied, statutory or otherwise as to its quality or fitness for purpose. Actual positions of assets should always be determined on site.



from
Southern Water